




System Configuration:
Fast Flat East-West, Without Spacer

